

2030 SPEERS ROAD | OAKVILLE, ONTARIO | L6L 2X8 | 1-888-945-5725 | 905-827-0224

**13462      05-UP      FORD      MUSTANG V6 CHIN SPOILER (V6 ONLY)**

## CONTENTS:

- |                          |                        |
|--------------------------|------------------------|
| 1 - Chin Spoiler         | 4 - 5/16" Lock Washers |
| 4 - 5/16" Hex Bolts      | 4 - 5/16" Hex Nuts     |
| 8 - 5/16" Fender Washers |                        |

## TOOLS REQUIRED FOR INSTALLATION

- 3/8" Drill Bit
- 7/32" Wrench
- Drill
- Marker
- 1/2" Wrench

## INSTALLATION & HARDWARE MOUNTING INSTRUCTIONS

### Please read thoroughly before beginning

1. Remove the factory hardware holding the front center splash shield to the lower front bumper cover (8 pcs).
2. Fit your new chin spoiler to these holes and fasten using original factory hardware.
3. Check alignment of chin spoiler.
4. Drill four 3/8" holes through the chin spoiler and into the factory bumper cover.
5. Install bolts, fender washer through the chin spoiler and bumper cover into fender washer lock-washers, nuts.
6. Tighten ALL hardware. **DO NOT OVER-TIGHTEN.**

## NOTE:

This chin spoiler will reduce available ground clearance in front of the vehicle. Use caution when approaching driveways, speed bumps, parking blocks or similar items on the road.

