

PAINT PRIOR TO INSTALLTION

PAINT INSTRUCTIONS

1. Wash with soap and warm water and thoroughly dry part. Wash with grease and silicone remover to be sure painted surface is clean.
2. Prep and sand (block sanding is recommended) with 320 grit sandpaper. Final sand with 400 grit. Scuff the entire surface with a fine or ultra fine scotch bright pad to remove any fine sanding or D/A scratches. Prime with a quality plastics primer/adhesion promotor.
3. Apply Basecoat/clearcoat as recommended by the paint manufacture.

**Remember the paint finish is only as good as the surface under it;
quality prep work is well worth the effort.**